

HaloLED Mains Dimmer Unit H3-RCV-AC1

Can be used to switch and dim mains voltage lighting circuits. The lamps must be dimmable and may be LED or Halogen types.

The maximum load must not exceed 1 Amp

Do not connect to low voltage (12 or 24v) lamps or equipment - this will cause damage.

Use on multiple lighting circuits :

Locate the HaloDim at the beginning of the lighting circuit, after the main switch. HaloDim requires both a live and a neutral feed but no earth. The live and neutral If an earth is present on the circuit then this must be continued around the HaloDim unit.

Please ensure this unit is installed in line with local electrical installation regulations



Pairing the HaloDim to a receiver:

Switch off the power and then turn it back on and then within 5 seconds, press the Zone Key that you wish to pair to 3 times in quick succession – the lights will flash 3 times to indicate pairing has been successful.

To deleting an existing pairing : Turn the power off and then back on and then within 5 seconds, press the Zone Key which has been paired, 5 times in quick succession – the lights will flash 5 times to indicate that the deletion has been successful.

Pairing multiple HaloDim units to a single control unit.

If you have several HaloDim unit on separate circuits, they can be allocated to different zones – to do this follow the pairing instructions given above – when you pair to a Zone, only one HaloDim will pair – if you then repeat the process, the second HaloDim will pair so we recommend that you allocate this to a different zone number meaning that they can be controlled independently.

Compatible with all HaloLED system controls:

- Universal Remote
- Applink
- 4 Scene Wall Switch
- 4 Zone Touch Panel